## NSN 4820-01-111-9588

Subplate Assembly - Page 1 of 1

Repairability:



iew Online at https://aerobasegroup.ae/nsn/4820-01-111-9588	
helf Life:	
l/a	
Init Of Measure:	
ea	
emilitarization:	
es - demil/mli	
lazmat:	
lo	

When repair is beyond lower level maintenance capability, evacuate the item to depot. disposal is not authorized below wholesale level.