

Push-pull Switch - Page 1 of 1



•

□ □

□
□

□ □

□ □

□

□ □

□ □

•

•

•

•

■

■

■

This is a nonreparable item. if condemned or economically unserviceable, then dispose at the level authorized replace the item.